

Zebra DS8108: Programming Barcodes for DS8108

Configuration name in Utility : Zebra DS8108
Last Modified : 01-Jun-26
Windows Filename : Zebra 8108 Imaging Scanner Setup - SNAPI.scncfg
Plug-in Name : DS8108-STANDARD DL MODELS-033
Report Type : Only parameters changed from defaults shown



Zebra DS8108: Programming Barcodes for DS8108

Configuration name in Utility : Zebra DS8108
Last Modified : 01-Jun-26
Windows Filename : Zebra 8108 Imaging Scanner Setup - SNAPI.scncfg
Plug-in Name : DS8108-STANDARD DL MODELS-033
Report Type : Only parameters changed from defaults shown



Set Factory Defaults

Cable Connection Settings

USB

USB Device Type SNAPI

IBM-RS485

PortAddress None

Keyboard Wedge

Terminal Type IBM AT Notebook

Imaging Settings

Imaging Parameters

Image Brightness (TargetWhite) 240

Image Enhancement High

JPEG Image Optimization

JPEG Quality Value 85

Snapshot Mode

Snapshot Mode Timeout No Timeout

Signature Capture

Signature Capture JPEG Quality 85

Image Cropping

Bottom Pixel Address 479

Zebra DS8108: Programming Barcodes for DS8108

Configuration name in Utility : Zebra DS8108
Last Modified : 01-Jun-26
Windows Filename : Zebra 8108 Imaging Scanner Setup - SNAPI.scncfg
Plug-in Name : DS8108-STANDARD DL MODELS-033
Report Type : Only parameters changed from defaults shown



Right Pixel Address 639

Video

Video View Finder Enable
Video View Finder Image Size 120
Video JPEG Quality 85
Video Resolution 1/3 Resolution

Intelligent Document Capture

IDC Operating Mode Linked
IDC X Coordinate 0
IDC Y Coordinate 0
IDC Width 640
IDC Height 480
IDC JPEG Quality 85
IDC Border Type Advanced Edge Detection (AED)
IDC Delay Time 6

Modify Data- Advanced Data Formatting

Prefix: |

1

1

2

Zebra DS8108: Programming Barcodes for DS8108

Configuration name in Utility : Zebra DS8108
Last Modified : 01-Jun-26
Windows Filename : Zebra 8108 Imaging Scanner Setup - SNAPI.scncfg
Plug-in Name : DS8108-STANDARD DL MODELS-033
Report Type : Only parameters changed from defaults shown



4

Suffix 1 Enter

7

0

1

3

Suffix 2 Enter

7

0

1

3

Scan Data Transmission Format <Prefix><Data><Suffix 1>

General Parameter Settings

System

Decode Session Timeout 5

Beeper

Beeper Volume Low

Beeper Tone Low

OCR

OCR-A Enable

Zebra DS8108: Programming Barcodes for DS8108

Configuration name in Utility : Zebra DS8108
Last Modified : 01-Jun-26
Windows Filename : Zebra 8108 Imaging Scanner Setup - SNAPI.scncfg
Plug-in Name : DS8108-STANDARD DL MODELS-033
Report Type : Only parameters changed from defaults shown



Configuration File

Zebra DS8108

Notes:

Zebra 8108 in FreeForm mode using SSI and 115200 baud

Firmware:

CAACZS00-010-R01