

DS8288 SNAP! Programming Barcodes for DS8288

Configuration name in Utility : DS8288 SNAP!
Last Modified : 19-Jul-26
Windows Filename : Zebra DS8288 Imaging Scanner Setup - SNAP!.scncfg
Plug-in Name : DS8288-STANDARD SR MODELS + CRADLE-005
Report Type : Only parameters changed from defaults shown



DS8288 SNAP! : Programming Barcodes for DS8288

Configuration name in Utility : DS8288 SNAP!
Last Modified : 19-Jul-26
Windows Filename : Zebra DS8288 Imaging Scanner Setup - SNAP!.scncfg
Plug-in Name : DS8288-STANDARD SR MODELS + CRADLE-005
Report Type : Only parameters changed from defaults shown



Set Defaults

Cable Connection Settings

USB

USB Device Type	SNAPI
-----------------	-------

Imaging Settings

Imaging Parameters

Image Brightness (TargetWhite)	120
Image Size (Number of Pixels)	1/2 Resolution
Image Enhancement	High

JPEG Image Optimization

JPEG Size Value	350
JPEG Quality Value	85

Snapshot Mode

Gain Exposure Priority	Low Gain Priority
Snapshot Mode Timeout	2 min
Silence Operational Mode Changes	Enable

BLUETOOTH

General Bluetooth Parameters

Radio Output Power	Low Power Setting
--------------------	-------------------



DS8288 SNAP! : Programming Barcodes for DS8288

Configuration name in Utility : DS8288 SNAP!
Last Modified : 19-Jul-26
Windows Filename : Zebra DS8288 Imaging Scanner Setup - SNAP!.scncfg
Plug-in Name : DS8288-STANDARD SR MODELS + CRADLE-005
Report Type : Only parameters changed from defaults shown



Beeper

Beeper Volume	Low
Scan Tone	Low
Pager Motor After Good Decode	Disable
Configuration File	DS8288 SNAP!

Firmware:

SAAGMS00-002-R02